

Floor Graphic - Indoor Installation Instructions

Surface Preparation:

1. Sweep the surface free of debris and dust for proper adhesion.
2. Ensure the surface is dry. If the surface is covered in grease or otherwise unclean, mop the area then allow it to dry before applying your graphic. A commercial degreaser may be needed for stubborn substances.
3. Avoid applying your graphic over any loose, unwanted substances that may affect the graphic's ability to properly adhere: namely; caked dirt, loose gravel, oils, grease, sand, etc.



Installation of large decals should be done with two or more people. Once your surface is cleaned and completely dried, remove the paper liner from the adhesive side of the decal. (For best results, ensure you place your decal precisely where you want to place it. Removing the decal and attempting to reposition it may result in unwanted creases and may weaken the decal's ability to adhere.)



Starting at one end of the vinyl decal, use a squeegee to slowly and smoothly adhere the decal to the installation surface making sure to press over the whole decal so that it adheres to the surface beneath.
NOTE: Make sure to secure outer edges of decal securely as failure to do so will result in damage to the decal.



The decal will begin to adhere immediately and will be ready for foot traffic once applied.



Do not clean graphics for at least 24 hours after installation..

Floor Graphic - OUTDOOR Installation Instructions

Surface Preparation:

1. Sweep the surface to ensure it is free of debris for proper adhesion.
2. Ensure the surface is dry. If the surface is greasy or otherwise unclean, power wash the area then allow it to dry before applying your graphic. A commercial degreaser may be necessary for stubborn substances.
3. Avoid applying your graphic over any loose or foreign substance that may affect the graphic's ability to properly adhere: namely; caked dirt, loose gravel, oils, grease, sand, etc.
4. A mixture of 50/50 to 70/30 percent isopropyl alcohol (IPA) + water can be used for surfaces where adhesion is difficult. After applying the solution, wipe with a soft cloth. A second pass often helps with adhesion.



Once your surface is clean and completely dry, remove the liner from the decal. Please note that the decal is not repositionable, so it's important that you lay it precisely where you want it on the desired surface. Avoid crinkling your decal in any way before application.



Lay the decal on the desired surface, pressing firmly from the center out to the edges, ensuring the material conforms to the surface beneath to maximize adhesion. For uneven surfaces it is best to apply the decal a little bit at a time to make sure it adheres as the decal is not stretchy by nature.

NOTE: Make sure to secure outer edges of decal securely as failure to do so will result in damage to the decal.



If needed, a hand roller can be used to ensure the decal is adhered evenly after initially pressing it to the surface with your hand.



Adhesion is instant and, once firmly pressed, the decal is immediately ready for foot traffic. However, it will take up to 24 hours for the decal's adhesive to fully dry.

NOTE: All Clark and Riggs floor decals may be damaged by pallets or heavy equipment, such as forklifts, as well as dragging heavy items across the top of the graphic.

Minor edge chipping is unavoidable.